Western Electric Co., Incorporated,
Engineering Dept.,
New York.

(2 Pages) Page #1. Issue 7 - BT-431141. March 2, 1920.

METHOD OF OPERATION MAKE BUSY CIRCUIT

Relay Call Indicator Trunk - Full Mechanical Switching System.

GEVERAL DESCRIPTION

1. This circuit is used between a manual relay call indicator office and a full mechanical office. Its purpose being to make groups of trunks incoming to the manual office busy at the mechanical office by the operation of a non-locking key at the manual office. This busy feature will prevent the mechanical apparatus at the mechanical office from selecting trunks to a relay call indicator position that is unoccupied. The operation of the non-locking key makes the group of trunks busy by connecting ground to their sleeve terminals and the second operation of the key disconnects the ground thereby removing the busy condition. The cam cuttings on cams E to T respectively are cut at different positions, this leing done to distribute the load through the contacts more evenly thereby reducing the chances of arcing.

DETAILED DESCRIPTION

CPERATION

2. When the "make busy" key at the manual relay call indicator office is operated, the circuit through the L relay is closed, causing the relay to operate, in turn causing the L-1 relay to operate and lock through its outer winding to ground on cam D provided the switch remains in position 1. The operation of the L-1 relay with the switch in position 1 causes the lamp at the monitoring board to light, the circuit being closed through cam C. The coerstion of the L-1 relay also closes a circuit through the motor magnet which operates and moves the switch to position 6. As soon as cams C and D move cut of position 1, the circuit through the lamp is opened, causing the lamp to be extinguished and also opening the circuit through the outer winding of the L-1 relay. In case the mechanism should not function so as to leave position 1, the lamp will remain lighted at the monitoring board as a trouble signal. In position 6 the trunks are made busy, ground being connected to their sleeves. When the make busy key is released, the L relay releases, in turn releasing the L-1 relay. The release of the L-1 relay causes the rotor magnet to operate and move the switch to position 7 and there keeping the trunks busy. The groups of trunks are made busy from positions 1-3/4 to 8 inclusive. When the key is again operated the operation is as previously described. The retor moves the switches into position 9 making the trunks idle, and when the key is released the switch is moved into position 1 restoring the circuit to normal.

Line was to start a got beginning to the terminal . "Duji ur inne Carried and the second of the A STATE OF THE STA The state of the state of the state and algorithms are the state of th ... progression of the second reconstruction of the second The first of the second second the second The service of the second of t the first of the control of the section of the section of the control of the cont na de la granda e guarda guarda por porta de porta de porta de proposición de porta de la composición del composición de la composición de la composición del composición de la composición de l the following the company of the second of t o production and the second section of the second second section of the second sec and the property of the community and a stage of the stage of A Sept March 15 to the beat from 16 with the table of the control The first of the second of the second of the second second of the second no de la company provinces and the complete of the contract of The second secon Consider the State of State of the State of n de la companya de Companya de la compa the state of the s

(2 Pages) Page #2. Issue 7 - BT-431141. March 2, 1920.

CIRCUIT REQUIREMENTS

	OPERATE	NON-OPERATE	RELEASE
B83	After a soak of approximately .021 amp. Test .005 amp. Re-adj0045 amp.		After a soak of approx- imately .021 amp. Test .0028 amp. Re-adj003 amp.
Spl. El30 per D-20490 (L-1) Inner Wag.	20 -4: 00 -	Test .009 amp. Re-adj010 amp.	
Outer Wdg.	Hold: Test .047 amp.		

1.98 772) XI. OF STREET, STATE OF THE STREET, STATE OF THE STREET, STATE OF THE STREET, STATE OF THE STATE OF -90-90 7500.4 *** 1.500. wire 4:0: (1000) - 3 STANKERS THE STANKE BEFORE A SERVICE AND A S and the second